

Multifunctional Counterfeit Detector (MCU) Instructions

1. Before usage, remove the all packaging such as the one protecting the UV tube



2. Changing the UV tube lamp

Easily unscrew the white holder on the left side. After pull out the broken UV tube lamp and change it for a new UV tube lamp. Screw the white holder back (not too strong to avoid breaking the plastic)

3. Changing the white tube

Carefully push on the black part to get the white part a little loose from the black part



4. Use a screwdriver or scissors

Carefully put the screwdriver or scissors between the materials. The white plastic plate will become loose now. Be careful with you fingers as the plastic can be sharp.



5. Changing the white tube lamp

Easily unscrew the white holder on the left side. After pull out the broken white tube lamp and change it for a new white tube lamp. Screw the white holder back (not too strong to avoid breaking the plastic).

6. Place the white plastic plate back at it's position

